

MASTER OF PLASTER TECHNICAL DATA SHEETS: **PLASTER WASHERS****COMPOSITION:**

#3 SLIT EDGE STEEL

SIZING:

.0140" DEPTH X 1" DIAMETER

APPLICATION:

PLASTER WASHERS ARE USED TO REATTACH CRACKING, SPAULING, LOOSE, AND FAILING PLASTER. ONCE THE PLASTER HAS LOST ITS KEY TO THE UNDERLYING WOOD OR METAL LATHE, YOU RISK LOSING THE PLASTER ALTOGETHER AS THE WEIGHT INTENSIFIES OVER TIME AND CAUSES GREATER STRESSES UPON THE SOUND, EXISTING PLASTER. ONCE CRACKING OR SAGGING IS NOTED PLASTER WASHERS SHOULD BE IMMEDIATELY INSTALLED TO AVOID ANY FURTHER DAMAGE.

FOR HAIRLINE CRACKING, PLASTER WASHERS SHOULD BE ATTACHED USING SCREWS BY SPACING OUT ABOUT 2" APART ALONG EITHER EDGE OF THE CRACKED PLASTER.

FOR PLASTER THAT HAS ALREADY BEEN LOST, EDGES SHOULD BE CLEANED BACK TO SOUND PLASTER AND THEN PLASTER WASHERS AND SCREWS SHOULD BE LOCATED APPROXIMATELY 5" APART ALONG EDGE OF FAILED PLASTER.

FOR SPAULING OR SAGGING PLASTER, USE THE STUD LINES OR JOIST LINES AND PULL THE PLASTER BACK TO THE WOOD SUBSTRATE. SPACING OF THE PLASTER WASHERS SHOULD BE LAID OUT TO CREATE A TIGHT, SEAMLESS SURFACE ONCE AGAIN.

MAKE SURE THAT EACH PLASTER WASHER SCREW IS HITTING A STUD OR UNDERLYING SUBSTRATE TO PULL THE EXISTING PLASTER BACK INTO A SOUND UNDERLYING SURFACE.



TEL: 803.403.5252
FAX: 803.749.6822
1030 DRAKE ST.
COLUMBIA, SC 29063

MASTER OF PLASTER FINISHING SYSTEMS, INC.

WWW.MASTEROFPLASTER.COM
INFO@MASTEROFPLASTER.COM
PLASTER1.WORDPRESS.COM